

RISCO UK Technical – Visual Explanation

Wireless Supervision


What is it?

Wireless Supervision

Supervision is a feature of the panel that checks to make sure that the detectors of the system are still alive and present.

If a detector does not 'report in' within the supervise time, it is declared LOST by the panel.

Panel Supervision default time is 3 hours




Wireless Supervision

When the supervise timer in the panel starts, it looks for a detector which has been programmed to be supervised and effectively 'marks it off' it's waiting list.

Counting and waiting to hear the devices...

Click to continue.

Zone 4 LOST !!



ZONE1	● ●	Heard Zone 1 ☺
ZONE2	● ●	Heard Zone 2 ☺
ZONE3	● ●	Heard Zone 3 ☺
ZONE4	●	NOT Heard Zone 4 ☹
ZONE5	● ●	Heard Zone 5 ☺

RISCO UK Technical – Visual Explanation

Wireless Supervision

Visually Explained
by RISCO Technical